


# User Manual for Smart Repeater

M423-13Ever1.0




\* Please read the user manual carefully before operation. The guide picture is for reference only. please in kind prevail.

1

## 1 Product Introduction

This Smart repeater adopts unique structure design and advanced signal extend technology, can strengthen the wireless signal, effectively eliminate blind signal area and enlarge the network coverage area, to avail the user to enjoy worry-free quality network. In addition, the repeater also has a night light function. On the APP, the user can turn on/off the light and adjust its brightness.

## 2 Product Pictures




2

## 3 Technical Parameters

Working Voltage: AC100-240V~50Hz/60Hz,10mA  
Backup Battery: 3.7V  $\approx$  ,720mAh  
Networking: Zigbee  
Wireless Distance:  $\leq$ 80 meters (in the open air)  
Working Temperature: -10°C ~ +50°C  
Working Humidity:  $\leq$ 95%RH (no condensation)  
Dimensions:  $\Phi$ 80mm\*32mm (not including plug)  
Slave Device: Max 6 sub-devices can be added

3


## Step 1



• Plug and play, installation free.

4

## Step 3



- According to the APP prompt, press the network button 3 times within 2 seconds, the green LED will flash quickly (5 times/second), and the APP prompts the networking is successful.
- The green LED keeps on 3 seconds and then goes off, indicating that the networking is successful. Refresh the APP interface, you'll see the new repeater device is in the gateway sub-device list.
- If the device has been added to the network, press the network button 3 times within 2 seconds, and the device will quit the network.

5

## 4 Backup Battery

Backup battery instruction  
Backup battery can work continuously 12 hours after AC mains is powered off

6

Notes:

\*The pictures shown are for reference only.  
\*As the technology is constantly updated, if actual operation is inconsistent with the user manual, the final interpretation rights is reserved to the manufacturer.